

- 2 INSTALL EXPANSION JOINTS AT SPRING LINES OF RADII AND AT MAXIMUM 300' INTERVALS AND 10' ON EACH SIDE OF EACH CATCH BASIN.
- 3 INSTALL CONTROL JOINT AT INTERVALS OF 20'.
- 5 ALL JOINTS SHALL BE PLACED AT RIGHT ANGLES TO THE EDGE OF THE CURB AND GUTTER.
- 6 CURB DOES NOT DROP FOR DRIVEWAY OPENINGS; ALSO KNOWN AS MOUNTABLE CURB.
- * NO EXPANSION JOINT NEEDED AT CURB IF SIDEWALK DIMENSION TO FACE OF CURB IS LESS THAN 4'
- ** DEFINES CURB CUT WIDTH



CITY ENGINEER'S OFFICE MARQUETTE, MICHIGAN 1100 WRIGHT STREET, MARQUETTE, MI 49855 PHONE (906)228-0440

STANDARD DETAILS

DRIVEWAY & APRON DETAIL WITH D2 **CURB AND GUTTER**

APPROVED BY: K. WHITTINGTON DRAWN BY: D. SALMON DATE: APRIL 25, 2016 PROJECT FOLDER: J: |CADFILES|STD DTLS FILE NAME: DRIVE DETAIL.DWG